

98048 (RED) / 98057 (BLUE) STEELMAN TOOL KADDY

CONTENTS LISTING:

- 1 ea. Tool Kaddy Head Weldment
- 1 ea. Socket Kaddy
- 1 ea. Stand
- 1 ea. 0.80" OD Pipe x 25" long with 1/2" pipe thread assembly Includes 1/2" NPT threaded tee fitting and 1/2" NPT Female x 1/2" NPT Female Coupler
- 3 ea. 1/2" NPT Male 3/8" NPT Female Hex Reducing Bushing
- 1 ea. 1/2" NPT Male 1/2" NPT Female threaded 90 degree elbow fitting
- 1 ea. Roll Teflon Tape

Air feed from the floor

INSTRUCTIONS FOR ASSEMBLY:

- 1. Locate and mount stand in desired location using 3/8" x 2.5" floor anchors (not included).
- 2. Determine if shop air will be plumbed in from the floor or the ceiling and insert the 25" long pipe with the tee fitting into the top of the stand.
 - a. For floor supplied air, orient with tee located on top. Wrap 1/2" NPT Male x 1/2" NPT Female threaded 90 degree ceiling and insert the 25" long pipe with the tee fitting. Screw elbow into coupler until tight. Elbow will align with oval hole located at the bottom of the stand.
 - b. For ceiling supplied air, orient with tee located on bottom.
- 3. Wrap supplied 1/2" NPT Male 3/8" NPT Female Hex Reducing Bushing with supplied Teflon Tape. Screw into both sides of tee fitting and elbow fitting or 1/2" female end of pipe as necessary.
 - a. For ceiling supplied air, you will be required to mount Tool Kaddy Head Weldment and Socket Kaddy prior to adding Hex Reducing Bushing to Female end of pipe.
- 4. To mount Tool Kaddy Head Weldment:
 - a. Align holes in Head Weldment to threaded holes in stand.
 - b. Install supplied hex head cap screws hand tight.
- 5. Socket Kaddy will lie within the Tool Kaddy Head Weldment tray.











